
USE GREEN LABELLED OR GREEN DOT ● COMPONENTS FOR STATIONARY DOCK CONSTRUCTION

HOW TO BUILD A 4' x 8' Stationary Dock






DESCRIPTION	LENGTH or PART #	QTY.
1 - End Stringer	2" x 6" x 96"	2
2 - Center Stringer	2" x 6" x 93"	1
3 - Side Stringer	2" x 6" x 45"	2
D - Backer Plate	DE87122F	12
E - Corner Leg Holder	DE86100F	4
F - Hinge Connector*	DE86103F	2
G - Joist Corner	DE95122F	2
H - Washer Plate	DE95123F	4
I - Leg Pipe, 6'8"	DE93168F	4
J - Carriage Bolt	3/8" x 2½"	40
K - Lock Washers	3/8"	40
L - Nuts	3/8"	40

^{*} Required if affixing dock sections or a ramp together. Note: items J, K & L included in packages of 8 in Kit DE85150F.

SQUARING YOUR DOCK STRUCTURE

Check the squareness by measuring from corner to corner of the frame in an "X" pattern as shown. The measurement should be +/- 1/4" between each other. Lock the framework into square by temporarily securing a piece of lumber (Z) across one corner as shown.


Reinforcing the leg pipes and choosing a leg pipe base for bottom conditions.



soft or sandy bottoms where the dock structure requires a more stable footing. Alternatively, if necessary, the base plate may be fastened to a concrete slab or footing for additional stability or in areas of strong currents or wave action.


DESCRIPTION	PART #	QTY.
0 - Leg Brace Set	DE89101F	6
M - Corner Leg Brace Holder	DE87107F	4
N - Side Leg Brace Holder	DE93105F	4
Q - Bottom Pad	DE94102F	4
P - Base Plate	DE86102F	4

Note: Several options and combinations available for stabilizing a stationary dock structure.



CONNECTING DOCK SECTIONS

When attaching dock sections, leg braces should always be used on the leading edge of each dock section for stability.



Where dock

sections are

shown


DOCK EDGE 4

STATIONARY DOCK HARDWARE - How To Guide

▲ STATIONARY DOCK ANCHORAGE


Drive leg pipes no less than 12" (30,5cm) into lake bed, 24" (61cm) if dock to be used for a boat mooring.

DESCRIPTION	LENGTH or PART #	QTY.
S - Chain Retainer	DE99013F	2
H - Washer Plate	DE95123F	4
Galvanized chain	5/16" x 48' approx	1
Hardware Fastener Kit	DE85150F	1
Anchorage	Min. 125lb ea.	2




GRADED SHORELINE INSTALLATION

- Use hinge DE86103F between dock segments.
- Allow leg pipes to protrude below the bottom pads by approximately 12" (30,5cm) so they will become embedded in the lake hed
- Adjust leg pipe holders on leg pipes to level dock segments before tightening.



UNEVEN SHORELINE INSTALLATION

- Use hinge DE86103F between dock segments.
- Allow the dock segment with the highest drop in elevation to act as a ramp to
- to act as a ramp to a maximum of 15° angle.
- Adjust leg pipe holders on leg pipes to sufficient contact with lake bed.
- Tighten leg holders.



Hardware & Fasteners required (referenced by item letter)



DE87122F Backer Plate



DE86100F Corner Leg Holder



DE86103F Connector Hinge



DE95122F Joist Corner



DE95123F Washer Plate



DE93168F | DE93110F 6' 8" | 10' Galvalume Leg Pipe, 2"



Carriage Bolts



Lock Washers



Nuts



M DE87107F



DE87107F DE93105FCorner Leg Brace Holder Leg Brace Holder



DE89101F Leg Brace Set



DE86102F Base Plate



DE94102F Bottom Pad



Deck Screws



DE99013F Chain Retainer



DE86104F Corner Plate



DE86101F Side Leg Holder



DE91111F Leg Cap

Hardware Requirements for Other Dock Sizes

DESCRIPTION	PART #	4 x 8 Dock	8 x 8 Dock	4 x 16 Dock	8 x 16 Dock
G - Joist Corner	DE95122F	2	6	6	18
H - Washer Plate	DE95123F	4	12	4	12
E - Corner Leg Holder	DE86100F	4	4	6	6
U - Side Leg Holder (optional)	DE86101F	4	4	6	4
M - Corner Leg Brace Holder	DE87107F	4	4	6	6
N - Side Leg Brace Holder	DE93105F	4	4	6	6
0 - Adjustable Leg Brace Set	DE89101F	6	6	12	12
I - Leg Pipe 6'8"	DE93168F	4	4	6	6
Q - Bottom Pad	DE94102F	4	4	6	6
P - Base Plate	DE86102F	May be used in combination with or in place of Bottom Pad DE94102F			
V - Pipe Cap	DE91111F	4	4	6	6
S - Chain Retainer	DE99013F	2 (Use at outer most end of dock structure up to 16' & every 16' thereafter)			
D - Backer Plate	DE87122F	12	12	18	18
Hardware Fastener Kit (8 pack Carriage Bolts, Lock Washers & Nuts)	DE85150F	5	8	10	14
F - Connector Hinge*	DE86103F	2	2	2	2
T - Corner Plate**	DE86104F	2	2	2	4

^{*} Connector Hinges used for between-dock and shore-to-dock or ramp connections and not required for individual dock sections.

^{**} Corner plate hardware to be used at dock-to-shore connection of dock where leg support is not required.




DOCK EDGE 4 STATIONARY DOCK HARDWARE - How To Guide

Tools Required for the average Dock Build


(excludes sizing/cutting of structural wood members)

- Electric Drill
- 3/16" drill bit
- 3/8" drill bit or auger
- 3/8" drive Socket wrench set
- Wrench set
- #2 Robertson (square) bit drive for decking screws
- Pencil
- · Measuring tape
- 2-1/2" hole saw (not required if mounting leg pipes on outer dock face)

Important Tips



Always use washer plates (DE95123F), backer plate (DE87122F) or mating hardware components together.




Attaching rolling wheels for dock insertion and removal

Dock Wheel Installation:

Adding wheels to a new or existing dock doesn't need to be complicated. By using Dock Edge + hardware, wheels can be attached simply and securely. The strongest connection needs to be between the dock and the wheel assembly—this is where the most stress occurs. To add wheels to a dock, substitute a standard Corner Plate (DE86104F) with a Corner Leg Holder (DE86100F) to hold a Galvalume Leg Pipe (DE93168F/DE93110F). This Leg Pipe becomes the strut that will later hold the axle. To provide additional insurance that the Leg Pipe won't move vertically, sandwich a standard Corner Plate between the Corner Leg Holder and the wood dock frame. Rotate the Corner Plate 90° so that it covers the top of the Leg Pipe. To further increase the lateral strength of the Leg Pipe add a Corner Leg Brace Holder (DE93105F/ DE87107F) and an arm from the Leg Brace Set (DE89101F) to the Leg Pipe. Bolt the other end of the arm from the Leg Brace Set to the wood dock frame. Repeat this procedure for the other side of the dock.

Wheel Strut Attachment Detail For Dock Insertion & Removal



Axle and wheel assembly:


Once the Leg Pipes are securely fastened to the wood dock frame, attach the axle pipe horizontally between the two leg pipes using a combination of **Side Leg Holders (DE86101F)** and **Backer Plates (DE87122F)**. Cut a short section of PVC pipe and slide over the axle to act as a bushing between the Dock Wheel and the Side Leg Holders. Next, drill two holes on either side of the axle end to accept a cotter pin. Slide the **Dock Wheel (DE90024F)** onto the axle followed by another PVC bushing. Install a cotter pin to secure the wheel. Repeat the procedure for each dock wheel.




DOCK EDGE 4


4' x 8' Stationary Dock

8' x 8' Stationary Dock






4' x 16' Stationary Dock



8' x 16' Stationary Dock



For your convenience, larger versions of these plans are available for download at www.dockedge.com

IMPORTANT: CMP Group Ltd. assumes no responsibility or liability for the accuracy or representation of the graphic illustrations shown in this hardware guide. These graphic illustrations are not intended to be architectural drawings, and are not to be substituted for engineered drawings. Each is intended as a guideline ONLY. CMP Group Ltd. does not warrant the quantities and/ or bill of materials to be accurate in all uses and applications. Individual dock structures may vary by necessity, preference or design. It may be necessary to vary the amount of materials listed in this guide depending on dock size, material usage, necessity and/ or the severity of the conditions to which the dock structure is subjected to. All graphic illustrations are based on the use of conventional framework of 2" x 6" lumber and decking lumber. Freeboard may be adjusted by using 2" x 8" or 2" x 10" lumber. Substitutions in lumber and hardware placement may affect floatation.

